

SIGNAL PROCESSING & SIMULATION NEWSLETTER

TUTORIAL 1 - Basic concepts in signal processing

Power and Energy

Energy of a pulse $g(t)$ is defined as

$$E = \int_{-\infty}^{+\infty} |g(t)|^2 dt \quad 1$$

This expression is very similar to expression 1 except that the resistance term is missing. By Parseval's Theorem, the Energy is defined in the frequency domain as

$$E = \int_{-\infty}^{+\infty} |G(f)|^2 df \quad 2$$

where $G(f)$ is the Fourier transform of pulse $g(t)$.

A signal is composed of a finite number of pulses, each of which these pulse have well-defined energy. However for signals, we generally speak in terms of power and not energy. Power is a more meaningful term since it can actually be measured. When we speak of Power, we may be talking about the following two things

1. Avg power of the signal and
2. Power Spectrum

Power is defined as energy over a specific time interval and is given by

$$P_g = \frac{1}{T} \int_0^T g^2(t) dt \quad 3$$

By evaluation of above integral we note, that Power is not a function of time. (-true only for wide-sense stationery processes.)

$$P_g = A_{avg}^2 T / T \quad 4$$

Example 1: Avg Power in a sine wave

For a sine wave of amplitude 1.0, its average amplitude is .707 (its RMS value). So the power of a sine wave is .5, as calculated below.

$$\frac{A^2}{2} = A_{avg}^2 \quad 5$$

Example 2: Power in a pulse

A rectangular pulse of amplitude A, power in the signal is A^2 .

Note that Power is interpreted as the Energy in one pulse of a periodic signal. Also the above definition of Power must be properly normalized for the impedance value of the signal to convert it to watts. This is one reason we typically use 1 ohm as our impedance. For an impedance other than 1 ohm, the power numbers calculated need to be adjusted.

For random processes, we define the power slightly differently as

$$P_x = Est[x^2(t)] \quad 6$$

which is simply the mean squared value of the instantaneous amplitude. At any point in the signal, the power of the signal is simply equal to its amplitude squared.

For a stationery process, the average power is however not a function of time and is simply the second moment or the variance of the signal $x(t)$.

$$P_x = Exp[x^2(t)] = Variance \quad 7$$

A signal with a large variance has large power. This is intuitively obvious. We use the above equation to model white noise processes of a given power value.

Noting the equivalence between variance and auto-correlation of a function, we introduce this relationship

$$P_x = R_x(0) = Variance \quad 8$$

What is auto-correlation of a signal?

It is a series of values obtained by the summing the individual values of the signal multiplied by a shifted version of itself. At zero shift, the time domain values coincide so we get the maximum sum. We say that the signal $x(t)$ and its zero shifted version $x(t-0)$ are perfectly correlated. Depending on the signal, any other value of the autocorrelation is likely to have a lower value.

The process of doing auto-correlation is exactly the same as computing the variance of the signal. The variance in fact is defined as the maximum value of the auto-correlation function and earlier we said that the variance of a signal is the measure of the power in the signal.

Expression . It states that the average power in a signal is equal to not only the variance but also the value of its auto-correlation function at time 0 which in turn are same.

Power or Energy per Bit

Often we talk of Energy per bit (E_b), when talking about signals. This is the average energy per bit of information transmitted. We define it as,

$$E_b = \frac{Avg[x^2(t)]}{R_b} \quad 9$$

where R_b is the bit rate.

Example 1: E_b of a sine wave

For a sine wave of amplitude 1, the average amplitude is .707. The energy per bit is calculated by

$$E_b = \frac{.707^2}{R_b} \quad 10$$

Example 2: E_b of a rectangular wave

For a rectangular pulse of amplitude 1, the average amplitude is 1. The energy per bit is $1/R_b$.

Power Spectrum and Power Spectral Density

Another way to look at the Power is to look its spectrum. The spectrum of a signal shows how much power is contained in each of its harmonic or spectral components or the frequency spectrum of the signal. A sine wave PSD has only a delta function at the carrier frequency since the signal contains just one spectral component namely the carrier frequency. A random signal on the other hand has a rich PSD with power occurring in many different components. Power spectrum of white noise is flat to show that power occurs in all frequencies.

A plot of the frequency components on the x-axis and attendant Power in that frequency on the y-axis is called the Power Spectrum of the signal. Its units are watts per Hertz. The Power Spectrum is also referred to as the Power Spectral Density. The two terms refer to the same thing. The Power spectrum does not directly give us the total or average power in the signal, only power in a particular spectral component. To obtain the total power in the signal or in a particular range, we must integrate the Power Spectrum over the range of frequencies of interest and include both negative and positive frequencies.

We can define total power now as the integral of the Power Spectral Density.

$$P_x = \frac{2}{2\pi} \int_0^{\infty} S_x(\omega) d\omega \quad 11$$

and

$$\hat{S} = 2S_x(\omega) \quad 12$$

where S_x is called the two-sided spectral density. We multiplied it by 2, because our integration limits were only the positive frequencies.

Properties of PSD and Power Spectrum

1. The total area under the Power Spectrum or PSD is equal to the total avg. power of the signal.
2. The PSD is always positive.
3. The PSD is an even function of frequency or in other words, it is symmetrical.
4. The auto-correlation function and PSD are a Fourier transform pair. To compute PSD, we compute the auto-correlation of the signal and then take its FFT. (Another estimation method called "periodogram" uses sampled FFT to compute the PSD.)
5. The value of the auto-correlation function at zero-time equals the total power in the signal.

Keep in mind that total or the average power in a signal is often not of as great an interest. We are most often interested in the PSD or the Power Spectrum. We often want to see is how the input power has been redistributed by the channel and in this frequency-based redistribution of power is where most of the interesting information lies.

Example 1 - Computing PSD of a Sine wave with random phase

Lets take a random sine wave

$$x(t) = A \cos(2\pi f_c t + \theta(t)) \quad 15$$


where $\theta(t)$ is the random phase from 0 to 360 degrees.

We compute the auto-correlation of this wave by the following relationship

$$R_x(\tau) = \frac{A^2}{2} \cos(2\pi f_c \tau) \quad 16$$

Now taking Fourier Transform of above, we get the PSD by the following relationship as shown below

$$S_x(f) = \frac{A^2}{4} [\delta(f - f_c) + \delta(f + f_c)] \quad 17$$



The PSD of the sine wave shows that power is concentrated at the carrier frequency and that the total power is the sum of the powers in both the negative and positive terms.

Now we can compute the total power from both of these relationships. From the auto-correlation, we see that by setting $t = 0$, we get

$$R_x(0) = \frac{A^2}{2} \quad 18$$

and by integrating the PSD (a trivial case here: $2 \times A^2/4$), we also get the same quantity. But unlike the signal power computation, the PSD also tells us that the power in this signal lies only at one frequency and is equal to twice the magnitude of the two-sided PSD. When interpreting PSD, it is important to note whether the given result is one or two-sided or the results will be off by 3 dB.

Most simulation programs do not use two-sided PSD but an alternate representation called the complex envelope. The complex envelope shifts the all energy in the positive axis and the PSD of a complex envelope signal is always one-sided and contains only the positive frequencies.


Example 2 - PSD of a Random binary wave

Now lets take a random binary wave where the 0 and 1's are defined by $x(t)$ and $-x(t)$ of amplitude $A =$

2 as shown in Figure above. The auto-correlation function of this wave is given by

$$R_x(\tau) = \begin{cases} A^2(1 - \frac{|\tau|}{T}) \\ 0 \end{cases}$$

19




Note that for an amplitude of 2, we should get the signal power as 4. In figure above, we see that the value of the auto-correlation function at its peak is exactly this number.

Now we compute the Power Spectral Density by taking the Fourier Transform of above. We get

$$S_x(f) = A^2T \text{ sinc}^2(fT)$$

20





The examination of the PSD tells us something interesting. It tells us that the maximum power occurs

in the spectral component at zero and the pattern of power drop-off follows the sinc function, a well-known result.

Now let's repeat the above calculations for a sine wave.

The auto-correlation function of a sine wave is also periodic. Above we calculated the power of a sine wave of amplitude $1 = .5$. From Figure below we see that the peak value of the auto-correlation function is indeed $.5$. The Power spectrum consists of a single spectral component at the wave frequency of 10 and is of magnitude 24.56 dBm (the dBm equivalent of the $.707$ rms amplitude).



But since a sine wave can correlate to itself every one period, its auto-correlation is periodic, however, each of the subsequent perfect correlation points are fewer in number so the total value of the auto-correlation, that is the sum, continues to decrease.

Periodogram

Periodogram is a computationally economical way of estimating the Power Spectrum. Mathematically we see that one needs to compute the auto-correlation of the whole sequence in order to get an accurate PSD. But for large sequences, this takes too long and an averaged PSD is computed instead. This averaged PSD is referred to as the Periodogram.

Periodogram method of computing the power spectrum also makes sense when the signal FFT is very noisy and a desired signal level can not be. In such cases, the inherent averaging of the Periodogram can help extract the signal.

We will discuss this method of assessing power in signals in much more detail later.

Exercise: Compute the auto-correlation function and the Power Spectrum of a sine wave with added noise.

Copyright 2000 Charan Langton

All Rights Reserved

mntcastle@earthlink.net